

# Swaging mandrels pro 4200-series fittings



Informace o produktu  
Skupina produkt

To control that the swaging has resulted in  
900

To control that the swaging has resulted in the right internal collapse. GO-side should pass through the fitting to make sure that the swaging is not overdone. The STOP-side should stop in the middle of the tail to ensure that the swaging is sufficient.

íslo položky	Rozmr (palce)
90150004	1/4"
90150006	3/8"
90150008	1/2"
90150010	5/8"
90150012	3/4"
90150016	1"
90150020	1 1/4"
90150024	1 1/2"
90150032	2"
90150305	3/16"

